

Xibita

ACROBAT

ROTATIONAL BANNER STAND


SET-UP GUIDE

STEP 1: GETTING STARTED



Place the base plate on the floor. Insert the telescoping bar and hub into the baseplate. Loosen the middle joint to extend the centre bar.

STEP 2: POLES



Insert the short and long poles into the centre hub.

STEP 3: HANG THE BANNER



Starting with the top hooks hang the banner, finishing with the bottom hooks on the poles.

STEP 4: ROTATE HUB



Loosen the hub's front knob to rotate the banner to suit. Loosen the rear knob to change the lean angle.

Xibita

ideas@xibita.com | 1 800 663 1737

xibita.com

Beyond Ordinary